

# RAK11300 Module AT Command Manual

## Introduction

---

RAK11300 WisDuo LPWAN Module is based on the Raspberry Pi RP2040 chip and SX1262 RF transceiver. It provides an easy-to-use, small-size, low-power solution for long-range wireless data applications. This module complies with Class A & C of LoRaWAN 1.0.2 specifications. It can easily connect to different LoRaWAN server platforms like TheThingsNetwork (TTN), Chirpstack, Helium, etc. It also supports LoRa Point-to-Point (P2P) communication mode which helps you in implementing your own customized long-range LoRa network quickly.

The AT commands can be interfaced via USB acting as a serial port (Pin 2 **USB\_DM** and Pin 3 **USB\_DP**) or via UART1 (Pin 10 **TX1** and Pin 9 **RX1**). The default parameter of the AT commands is fixed to **115200 / 8-N-1**. The firmware upgrade is only possible via USB. To get familiar with the pin distribution of this module and find a schematic circuit of a reference application, refer to the [RAK11300 Module Datasheet](#).

## Content

---

- [RAK11300 Module AT Command Manual](#)
  - [Introduction](#)
  - [Content](#)
  - [AT Command Syntax](#)
  - [AT?](#)
  - [ATR](#)
  - [ATZ](#)
  - [AT+APPEUI](#)
  - [AT+APPKEY](#)
  - [AT+DEVEUI](#)
  - [AT+APPSKEY](#)
  - [AT+NWKSKEY](#)
  - [AT+DEVADDR](#)
  - [AT+CFM](#)
  - [AT+JOIN](#)
  - [AT+NJS](#)
  - [AT+NJM](#)
  - [AT+SENDFREQ](#)
  - [AT+SEND](#)
  - [AT+ADR](#)
  - [AT+CLASS](#)
  - [AT+DR](#)
  - [AT+TXP](#)
  - [AT+BAND](#)
  - [AT+MASK](#)
  - [AT+BAT](#)
  - [AT+RSSI](#)
  - [AT+SNR](#)
  - [AT+VER](#)
  - [AT+STATUS](#)
  - [Appendix](#)
    - [Appendix I Data Rate by Region](#)
    - [Appendix II TX Power by Region](#)
    - [Appendix III Maximum Transmission Load by Region](#)

# AT Command Syntax

The AT command is based on ASCII characters. In general, the AT Command starts with the prefix `AT` and ends with `<CR><LF>` (i.e. `\r\n`). For the rest of the document, the `\r\n` part is omitted for the sake of clarity.

The AT commands have the standard format “AT+XXX”, with XXX denoting the command.

There are four available command formats:

AT COMMAND FORMAT	Description
<code>AT+XXX?</code>	Provides a short description of the given command
<code>AT+XXX=?</code>	Reading the current value on the command
<code>AT+XXX=&lt;input parameter&gt;</code>	Writing configuration on the command
<code>AT+XXX</code>	Used to run a command

The output of the commands is returned via UART.

The format of the reply is divided into two parts: returned value and the status return code.

 <b>NOTE:</b>
<code>&lt;CR&gt;</code> stands for “carriage return” and <code>&lt;LF&gt;</code> stands for “line feed”.

- `<value><CR><LF>` is the first reply when (`AT+XXX?`) command description or (`AT+XXX=?`) reading value is executed then it will be followed by the status return code. The formats with no return value like (`AT+XXX=<input parameter>`) writing configuration command and (`AT+XXX`) run command will just reply to the status return code.
- `<CR><LF><STATUS><CR><LF>` is the second part of the reply which is the status return code.

The possible status codes are:

STATUS RETURN CODE	Description
<code>OK</code>	Command executed correctly without error.
<code>+CME ERROR:1</code>	Generic error or input is not supported.
<code>+CME ERROR:2</code>	Command not allowed.
<code>+CME ERROR:5</code>	The input parameter of the command is wrong.
<code>+CME ERROR:6</code>	The parameter is too long.
<code>+CME ERROR:8</code>	Value out of range.

More details on each command description and examples are given in the remainder of this section.

**NOTE:**

After changing LoRaWAN® parameters, the device must be reset by either the `ATZ` command or pushing the reset button.

The Serial port connection is lost after the `ATZ` command or pushing the reset button. The connection must be re-established on the connected computer before log output can be seen or AT commands can be entered again.

## AT?

Description: Help

Returns a list of all available commands with a short description

Command	Input Parameter	Return Value	Return Code
<code>AT?</code>	-	<i>List of commands</i>	<code>OK</code>

```
AT?  
AT?  
  
+++++  
AT command list  
+++++  
AT?      AT commands  
ATR     Restore default  
ATZ     ATZ Trig a MCU reset  
AT+APPEUI    Get or set the application EUI  
AT+APPKEY    Get or set the application key  
AT+DEVEUI    Get or set the device EUI  
AT+APPSKEY   Get or set the application session key  
AT+NWKSKEY   Get or Set the network session key  
AT+DEVADDR   Get or set the device address  
AT+CFM     Get or set the confirm mode  
AT+JOIN    Join network  
AT+NJS     Get the join status  
AT+NJM     Get or set the network join mode  
AT+SENDFREQ Get or Set the automatic send time  
AT+SEND     Send data  
AT+ADR     Get or set the adaptive data rate setting  
AT+CLASS    Get or set the device class  
AT+DR      Get or Set the Tx DataRate=[0..7]  
AT+TXP     Get or set the transmit power  
AT+BAND   Get and Set number corresponding to active regions  
AT+MASK    Get and Set channels mask  
AT+BAT     Get battery level  
AT+RSSI   Last RX packet RSSI  
AT+SNR    Last RX packet SNR  
AT+VER    Get SW version  
AT+STATUS  Show LoRaWAN status  
+++++
```

`OK`

[Back](#)

## ATR

This command is used to restore all parameters to the initial default values of the module.

Command	Input Parameter	Return Value	Return Code
ATR?	-	-	OK
ATR	-	-	OK

[Back](#)

## ATZ

Description: MCU reset

This command is used to trigger an MCU reset.

Command	Input Parameter	Return Value	Return Code
ATZ?	-	ATZ: Trig a MCU reset	OK
ATZ	-	No return. MCU resets.	OK

[Back](#)

## AT+APPEUI

Description: Application unique identifier

This command is used to access and configure the APPEUI.

Command	Input Parameter	Return Value	Return Code
AT+APPEUI?	-	AT+APPEUI : Get or set the App Eui	OK
AT+APPEUI=?	-	< 8 hex >	OK
AT+APPEUI=<Input Parameter>	< 8 hex >	-	OK or AT_PARAM_ERROR

**Examples:**

```
AT+APPEUI?  
  
+APPEUI: Get or set the application EUI  
OK  
  
AT+APPEUI=?  
  
AT+APPEUI:70b3d57ed00201e1  
OK  
  
AT+APPEUI=70b3d57ed00201e1  
  
OK  
  
AT+APPEUI=70b3d57ed00201eh  
  
+CME ERROR:5
```

[Back](#)

## AT+APPKEY

Description: Application key

This command is used to access and configure the APPKEY.

Command	Input Parameter	Return Value	Return Code
AT+APPKEY?	-	AT+APPKEY : Get or set the Application Key	OK
AT+APPKEY=?	-	< 16 hex >	OK
AT+APPKEY=<Input Parameter>	< 16 hex >	-	OK or AT_PARAM_ERROR

**Examples:**

AT+APPKEY?

AT+APPKEY: Get or set the application key  
OK

AT+APPKEY=?

AT+APPKEY:2b84e0b09b68e5cb42176fe753dcee79  
OK

AT+APPKEY=2b84e0b09b68e5cb42176fe753dcee79

OK

AT+APPKEY=2b84e0b09b68e5cb42176fe753dcee7x

+CME ERROR:5

[Back](#)

## AT+DEVEUI

Description: Device EUI or DEVEUI

This command is used to access and configure the device EUI or DEVEUI.

Command	Input Parameter	Return Value	Return Code
AT+DEVEUI?	-	AT+DEVEUI : Get or set the Device EUI	OK
AT+DEVEUI=?	-	< 8 hex >	OK
AT+DEVEUI=<Input Parameter>	< 8 hex >	-	OK or AT_PARAM_ERROR

**Examples:**

```
AT+DEVEUI?  
  
+DEVEUI: Get or set the device EUI  
OK  
  
AT+DEVEUI=?  
  
+DEVEUI:ac1f09ffffe03efdc  
OK  
  
AT+DEVEUI=ac1f09ffffe03efdc  
  
OK  
AT+DEVEUI=ac1f09ffffe03efdx  
  
+CME ERROR:5
```

[Back](#)

## AT+APPSKEY

Description: Application session key

This command is used to access and configure the application session key or APPSKEY.

Command	Input Parameter	Return Value	Return Code
AT+APPSKEY?	-	AT+APPSKEY : Get or set the Application Session Key	OK
AT+APPSKEY=?	-	< 16 hex >	OK
AT+APPSKEY=<Input Parameter>	< 16 hex >	-	OK or AT_PARAM_ERROR

**Examples:**

```
AT+APPSKEY?
```

```
AT+APPSKEY: Get or set the application session key  
OK
```

```
AT+APPSKEY=?
```

```
AT+APPSKEY:3f6a66459d5edca63cbc4619cd61a11e  
OK
```

```
AT+APPSKEY=3f6a66459d5edca63cbc4619cd61a11e
```

```
OK
```

```
AT+APPSKEY=3f6a66459d5edca63cbc4619cd61a11x
```

```
+CME ERROR:5
```

[Back](#)

## AT+NWKSKEY

Description: Network session keys

This command is used to access and configure the network session keys or NWKSKEY.

Command	Input Parameter	Return Value	Return Code
AT+NWKSKEY?	-	AT+NWKSKEY : Get or set the Network Session Key	OK
AT+NWKSKEY=?	-	< 16 hex >	OK
AT+NWKSKEY=<Input Parameter>	< 16 hex >	-	OK or AT_PARAM_ERROR

**Examples:**

```
AT+NWKSKEY?
```

```
AT+NWKSKEY: Get or Set the network session key  
OK
```

```
AT+NWKSKEY=?
```

```
AT+NWKSKEY:323d155a0000df335307a16da0c9df53f  
OK
```

```
AT+NWKSKEY=323d155a0000df335307a16da0c9df53f
```

```
OK
```

```
AT+NWKSKEY=323d155a0000df335307a16da0c9df53f0
```

```
+CME ERROR:5
```

[Back](#)

## AT+DEVADDR

Description: Device address or DEVADDR

This command is used to access and configure the device address or DEVADDR.

Command	Input Parameter	Return Value	Return Code
AT+DEVADDR?	-	AT+DEVADDR : Get or set the device address	OK
AT+DEVADDR=?	-	< 4 hex >	OK
AT+DEVADDR=<Input Parameter>	< 4 hex >	-	OK or AT_PARAM_ERROR

**Examples:**

```
AT+DEVADDR?
```

```
AT+DEVADDR: Get or set the device address  
OK
```

```
AT+DEVADDR=?
```

```
AT+DEVADDR:26021FB0
```

```
OK
```

```
AT+DEVADDR=26021FB0
```

```
OK
```

```
AT+DEVADDR=26021FBX
```

```
+CME ERROR:5
```

[Back](#)

## AT+CFM

Description: Confirmed payload mode

This command is used to access and configure the type of payload of the device.

Command	Input Parameter	Return Value	Return Code
AT+CFM?	-	AT+CFM : Get or set the confirm mode	OK
AT+CFM=?	-	0 (if Unconfirmed) or 1 *if confirmed)	OK
AT+CFM=<Input Parameter>	0 or 1	-	OK or AT_PARAM_ERROR

**Examples:**

```

AT+CFM?

AT+CFM: Get or set the confirm mode
OK

AT+CFM=?

AT+CFM:0
OK

AT+CFM=0

OK

AT+CFM=3

+CME ERROR:5

```

[Back](#)

## AT+JOIN

Description: Join the LoRaWAN® network

This command is used to join a LoRaWAN® network.

Command	Input Parameter	Return Value	Return Code
AT+JOIN?	-	AT+JOIN : Join network	OK
AT+JOIN=?	-	Param1, Param2, Param3, Param4	OK or AT_BUSY_ERROR
AT+JOIN=<Input Parameter>	Param1:Param2:Param3:Param4	-	OK
	Param1 = <b>Join command</b> : 1 for joining the network, 0 for stop joining		
	Param2 = <b>Auto-Join config</b> : 1 for Auto-join on power up), 0 for no auto-join. (0 is default)		
	Param3 = <b>Reattempt interval</b> : 7 - 255 seconds (30 is default)		
	Param4 = <b>No. of join attempts</b> : 0 - 255 (0 is default)		

**NOTE**

- This is an asynchronous command. **OK** means that the device is joining. The completion of the JOIN can be verified with **AT+NJS=?** command.
- Param3 is not supported yet and is fixed to 30 seconds always.

**Examples:**

```
AT+JOIN?  
  
AT+JOIN: Join network  
OK  
  
AT+JOIN=?  
  
AT+JOIN=0:1:8:10  
OK  
  
AT+JOIN=1:1:8:10  
  
OK  
  
AT+JOIN=SUCCESS  
  
AT+JOIN=3:1:8:10  
  
+CME ERROR:5
```

[Back](#)

## AT+NJS

Description: Network join status

This command is used to check the status of the devices if it is connected to a LoRaWAN® network.

Command	Input Parameter	Return Value	Return Code
<b>AT+NJS?</b>	-	<b>AT+NJS</b> : Get the join status	<b>OK</b>
<b>AT+NJS=?</b>	-	<b>0</b> (not joined) or <b>1</b> (joined)	<b>OK</b>

**Examples:**

```
AT+NJS?
```

```
AT+NJS: Get the join status  
OK
```

```
AT+NJS=?
```

```
AT+NJS:1  
OK
```

[Back](#)

## AT+NJM

Description: LoRaWAN® network join mode

This command is used to access and configure the activation method of the device either OTAA or ABP. A value of 1 means OTAA join mode, a value of 0 means ABP join mode

Command	Input Parameter	Return Value	Return Code
AT+NJM?	-	AT+NJM : Get or set the network join mode	OK
AT+NJM=?	-	0 or 1	OK
AT+NJM=<Input Parameter>	0 or 1	-	OK or AT_PARAM_ERROR

### Examples:

```
AT+NJM?
```

```
AT+NJM: Get or set the network join mode  
OK
```

```
AT+NJM=?
```

```
AT+NJM:0  
OK
```

```
AT+NJM=0
```

```
OK
```

```
AT+NJM=2
```

```
+CME ERROR:5
```

[Back](#)

## AT+SENDFREQ

Description: Set the automatic transmission period

This command is used to set the period in seconds between automatic packet transmissions. If set to 0, automatic packet transmission is disabled.

Command	Input Parameter	Return Value	Return Code
AT+SENDFREQ?	-	AT+SENDFREQ : Get or set the automatic send time	OK
AT+SENDFREQ=?	-	<period in seconds>	OK
AT+SENDFREQ=<Input Parameter>	<period in seconds>	-	OK or AT_PARAM_ERROR

#### Examples:

```
AT+SENDFREQ?
```

```
AT+SENDFREQ: Get or Set the automatic send time
OK
```

```
AT+SENDFREQ=?
```

```
AT+SENDFREQ:60
OK
```

```
AT+SENDFREQ=60
```

```
OK
```

[Back](#)

## AT+SEND

Description: Send payload data

This command is used to send the LoRaWAN® payload to a specific port.

Command	Input Parameter	Return Value	Return Code
AT+SEND?	-	AT+SEND : Send data	OK
AT+SEND=<Input Parameter>	port:payload	-	OK , AT_NO_NETWORK_JOINED , AT_PARAM_ERROR , or AT_BUSY_ERROR

#### Examples:

```
AT+SEND?
```

```
AT+SEND: Send data  
OK
```

#### Unconfirmed Payload

```
AT+SEND=2:1234
```

```
OK
```

```
AT+SEND=SUCCESS
```

#### Confirm Payload

```
AT+SEND=2:1234
```

```
OK
```

```
AT+SEND=SUCCESS
```

#### Downlink packet received

 **NOTE:**

- If there is a pending downlink message from the LNS (LoRaWAN Network Server), the downlink payload will be received after the `AT+SEND` command with the format `<fport>:<data length>:<rssi>:<snr>:<data>`.
- In this example, the format has the corresponding values:
  - **fport:** 2
  - **data length:** 6
  - **rssi:** -46 dBm
  - **snr:** 11 dB
  - **data payload:** 48656C6C6F0A

```
AT+SEND=5:10AAFF45
```

```
OK
```

```
AT+SEND=SUCCESS
```

```
RX:2:6:-46:11:48656C6C6F0A
```

```
OK
```

[Back](#)

**AT+ADR**

Description: Adaptive data rate

This command is used to access and configure the adaptive data rate of the module.

Command	Input Parameter	Return Value	Return Code
AT+ADR?	-	AT+ADR : Get or set the Adaptive Data Rate setting	OK
AT+ADR=?	-	0 (ADR off) or 1 (ARD on)	OK
AT+ADR=<Input Parameter>	0 or 1	-	OK or AT_PARAM_ERROR

#### Examples:

```

AT+ADR?
+ADR: Get or set the adaptive data rate setting
OK

AT+ADR=?

AT+ADR:0
OK

AT+ADR=0
OK

AT+ADR=3

+CME ERROR:5

```

[Back](#)

## AT+CLASS

Description: LoRaWAN® class

This command is used to access and configure the LoRaWAN® class of the module.

Command	Input Parameter	Return Value	Return Code
AT+CLASS?	-	AT+CLASS : Get or set the Device Class (A, B, C)	OK
AT+CLASS=?	-	A or C (B not supported)	OK
AT+CLASS=<Input Parameter>	A or C	-	OK or AT_PARAM_ERROR

*This FW of the device supports the LoRaWAN® V1.0.2 stack.*

**Examples:**

```
AT+CLASS?  
  
+CLASS: Get or set the device class  
OK  
  
AT+CLASS=?  
  
AT++CLASS:A  
OK  
  
AT+CLASS=A  
  
OK  
  
AT+CLASS=F  
  
+CME ERROR:5
```

[Back](#)

## AT+DR

Description: Data rate settings

This command is used to access and configure data rate settings.

Command	Input Parameter	Return Value	Return Code
AT+DR?	-	AT+DR=<DataRate><CR> : Get or set the Tx Data Rate	OK
AT+DR=?	-	0 , 1 , 2 , 3 , 4 , 5 , 6 , 7	OK
AT+DR= <Input Parameter>	0 , 1 , 2 , 3 , 4 , 5 , 6 , 7	-	OK or AT_PARAM_ERROR

Check [Appendix I](#) for the input parameter depending on the frequency band selected.

**Examples:**

```

AT+DR?

AT+DR: Get or Set the Tx DataRate=[0..7]
OK

AT+DR=?

AT+DR:3
OK

AT+DR=3

OK

```

[Back](#)

## AT+TXP

Description: Transmit Power

This command is used to access and configure the transmit power.

Command	Input Parameter	Return Value	Return Code
AT+TXP?	-	AT+TXP : Get or set the transmit power	OK
AT+TXP=?	-	< value >	OK or AT+PARAM_ERROR
AT+TXP=<Input Parameter>	< value >	-	OK or AT_PARAM_ERROR

Check [Appendix II](#) for the input parameter depending on the frequency band selected.

For example, at EU868, a value of 2 represents **MaxEIRP - 4 dB** where MaxEIRP = +16 dBm.

### Examples:

```

AT+TXP?

AT+TXP: Get or set the transmit power
OK

AT+TXP=?

AT+TXP:0
OK

AT+TXP=0

OK

```

[Back](#)

# AT+BAND

Description: Regional frequency band

This command is used to access and configure the regional frequency band.

Command	Input Parameter	Return Value	Return Code
AT+BAND?	-	AT+BAND : Get and Set number corresponding to active regions	OK
AT+BAND=?	-	0 , 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 11 , 12	OK
AT+BAND=<Input Parameter>	< 0 to 12 >	-	OK or AT_PARAM_ERROR

## List of Band Parameter Options

Code	Regional Band	Code	Regional Band
0	AS923-1	7	IN865
1	AU915	8	US915
2	CN470	9	AS923-2
3	CN779	10	AS923-3
4	EU433	11	AS923-4
5	EU868	12	RU864
6	KR920		

## Examples:

AT+BAND?

AT+BAND: Get and Set number corresponding to active regions  
OK

AT+BAND=?

AT+BAND:10  
OK

AT+BAND=10

OK

AT+BAND=22

+CME ERROR:8

[Back](#)

## AT+MASK

Description: Regional channel mask

This command is used to access and configure the regional channel mask. Channel mask can only be set for the following regions: AU915, CN470, and US915

Command	Input Parameter	Return Value	Return Code
AT+MASK?	-	AT+MASK: Get and Set channels mask	OK
AT+MASK=?	-	1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 11 , 12	OK
AT+MASK=<Input Parameter>	< 0 to 12 >	-	OK or AT_PARAM_ERROR

**List of mask channels per region**

<b>Mask (Sub-Band)</b>	<b>US915</b>	<b>AU915</b>	<b>CN470</b>
1	0-7	0-7	0-7
2	8-15	8-15	8-15
3	16-23	16-23	16-23
4	24-31	24-31	24-31
5	32-39	32-39	32-39
6	40-47	40-47	40-47
7	48-55	48-55	48-55
8	56-63	56-63	56-63
9	-	-	64-71
10	-	-	72-79
11	-	-	80-87
12	-	-	88-95

#### Examples:

```

AT+MASK?
AT+MASK: Get and Set channels mask
OK

AT+MASK=?
AT+MASK:10
OK

AT+MASK=10
OK

AT+MASK=13
+CME ERROR:8

```

[Back](#)

## AT+BAT

Description: Read the battery voltage

This command is used to read the battery voltage of the device

Command	Input Parameter	Return Value	Return Code
AT+BAT?	-	AT+BAT : Get battery level	OK
AT+BAT=?	-	< value >	OK or AT+PARAM_ERROR

#### NOTE:

The battery level is returned as a value between 0 and 255.

#### Examples:

```
AT+BAT?
+BAT:"Get battery level"
OK

AT+BAT=?
+BAT:254
OK
```

[Back](#)

## AT+RSSI

Description: Receive signal strength indicator

This command is used to get the RSSI value of the last packet received.

Command	Input Parameter	Return Value	Return Code
AT+RSSI?	-	AT+RSSI : Get the RSSI of the last received packet	OK
AT+RSSI=?	-	< integer > in dBm	OK

#### NOTE:

The reply will be '0' if there is no last packet received yet.

#### Examples:

```
AT+RSSI?  
  
AT+RSSI: Last RX packet RSSI  
OK  
  
AT+RSSI=?  
  
AT+RSSI:-41  
OK
```

[Back](#)

## AT+SNR

Description: Signal to Noise Ratio

This command is used to get the SNR value of the last packet received.

Command	Input Parameter	Return Value	Return Code
AT+SNR?	-	AT+SNR : Get the SNR of the last received packet	OK
AT+SNR=?	-	<integer> in dB	OK

 **NOTE:**

The reply will be '**0**' if there is no last packet received yet.

### Examples:

```
AT+SNR?  
  
AT+SNR: Last RX packet SNR  
OK  
  
AT+SNR=?  
  
AT+SNR:11  
OK
```

[Back](#)

## AT+VER

Description: Version of the firmware

This command is used to get the firmware version installed on the device.

Command	Input Parameter	Return Value	Return Code
AT+VER?	-	AT+VER : Get the version of the firmware	OK
AT+VER=?	-	< V.x.y >	OK

**Examples:**

```
AT+VER?
AT+VER: Get SW version
OK

AT+VER=?

AT+VER:1.0.0.0 May 27 2021 17:11:12
OK
```

[Back](#)

## AT+STATUS

Description: Show device status

This command is used to get the current device status.

Command	Input Parameter	Return Value	Return Code
AT+STATUS?	-	AT+STATUS : Show LoRaWAN status	OK
AT+STATUS=?	-	< status >	OK

**Examples:**

AT+STATUS?

AT+STATUS: Show LoRaWAN status  
OK

AT+STATUS=?

LoRaWAN status:

Auto join disabled  
OTAA enabled  
Dev EUI 5032333338350012  
App EUI 1200353833333250  
App Key 5032333338350012120035383333250  
NWS Key 5032333338350012120035383333250  
Apps Key 5032333338350012120035383333250  
Dev Addr 83986D12  
Repeat time 120000  
ADR disabled  
Public Network  
Dutycycle disabled  
Join trials 10  
TX Power 0  
DR 3  
Class 0  
Subband 1  
Fport 2  
Unconfirmed Message  
Region 10  
Network joined  
Mode User

+STATUS:

OK

[Back](#)

## Appendix

### Appendix I Data Rate by Region

EU433/EU868/RU864/AS923

Data Rate	Configuration	Indicative Physical Bit Rate [bit/s]
0	LoRa: SF12 / 125 kHz	250
1	LoRa: SF11 / 125 kHz	440
2	LoRa: SF10 / 125 kHz	980
3	LoRa: SF9 / 125 kHz	1760
4	LoRa: SF8 / 125 kHz	3125
5	LoRa: SF7 / 125 kHz	5470
6	LoRa: SF7 / 250 kHz	11000
7	FSK: 50 kbps	50000
8 ~ 15	RFU	

#### CN470/KR920

Data Rate	Configuration	Indicative Physical Bit Rate [bit/s]
0	LoRa: SF12 / 125 kHz	250
1	LoRa: SF11 / 125 kHz	440
2	LoRa: SF10 / 125 kHz	980
3	LoRa: SF9 / 125 kHz	1760
4	LoRa: SF8 / 125 kHz	3125
5	LoRa: SF7 / 125 kHz	5470
6 ~ 15	RFU	

#### US915

Data Rate	Configuration	Indicative Physical Bit Rate [bit/s]
0	LoRa: SF10 / 125 kHz	980
1	LoRa: SF9 / 125 kHz	1760
2	LoRa: SF8 / 125 kHz	3125
3	LoRa: SF7 / 125 kHz	5470
4	LoRa: SF8 / 500 kHz	12500
5 ~ 7	RFU	
8	LoRa: SF12 / 500 kHz	980
9	LoRa: SF11 / 500 kHz	1760
10	LoRa: SF10 / 500 kHz	3900
11	LoRa: SF9 / 500 kHz	7000
12	LoRa: SF8 / 500 kHz	12500
13	LoRa: SF7 / 500 kHz	21900
14 ~ 15	RFU	

AU915

Data Rate	Configuration	Indicative Physical Bit Rate [bit/s]
0	LoRa: SF12 / 125 kHz	250
1	LoRa: SF11 / 125 kHz	440
2	LoRa: SF10 / 125 kHz	980
3	LoRa: SF9 / 125 kHz	1760
4	LoRa: SF8 / 125 kHz	3125
5	LoRa: SF7 / 125 kHz	5470
6	LoRa: SF8 / 500 kHz	12500
7	RFU	RFU
8	LoRa: SF12 / 500 kHz	980
9	LoRa: SF11 / 500 kHz	1760
10	LoRa: SF10 / 500 kHz	3900
11	LoRa: SF9 / 500 kHz	7000
12	LoRa: SF8 / 500 kHz	12500

IN865

<b>Data Rate</b>	<b>Configuration</b>	<b>Indicative Physical Bit Rate [bit/s]</b>
0	LoRa: SF12 / 125 kHz	250
1	LoRa: SF11 / 125 kHz	440
2	LoRa: SF10 / 125 kHz	980
3	LoRa: SF9 / 125 kHz	1760
4	LoRa: SF8 / 125 kHz	3125
5	LoRa: SF7 / 125 kHz	5470
6	RFU	RFU
7	FSK: 50 kbps	50000
8 ~ 15	RFU	RFU

[Back](#)

## Appendix II TX Power by Region

### EU868

By default, MaxEIRP is considered to be +16 dBm.

<b>TXPower</b>	<b>Configuration (EIRP)</b>
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8 ~ 15	RFU

**US915**

<b>TXPower</b>	<b>Configuration (Conducted Power)</b>
0	30 dBm - 2*TXpower
1	28 dBm
2	26 dBm
3 ~ 9	-
10	10 dBm
11 ~ 15	RFU

**AU915**

By default, MaxEIRP is considered to be +30 dBm.

<b>TXPower</b>	<b>Configuration (EIRP)</b>
0	MaxEIRP
1 ~ 10	MaxEIRP - 2*TXPower
11 ~ 10	RFU

**KR920**

By default, MaxEIRP is considered to be +14 dBm.

<b>TXPower</b>	<b>Configuration (EIRP)</b>
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8 ~ 15	RFU

## AS923

By default, Max EIRP is considered to be 16 dBm.

<b>TXPower</b>	<b>Configuration (EIRP)</b>
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8 ~ 15	RFU

## IN865

By default, MaxEIRP is considered to be 30 dBm.

TXPower	Configuration (EIRP)
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8	MaxEIRP - 16 dB
9	MaxEIRP - 18 dB
10	MaxEIRP - 20 dB
11 ~ 15	RFU

## RU864

By default, MaxEIRP is considered to be +16 dBm.

<b>TXPower</b>	<b>Configuration (EIRP)</b>
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8 ~ 15	RFU

## CN470

By default, MaxEIRP is considered to be +19.15 dBm.

<b>TXPower</b>	<b>Configuration (EIRP)</b>
0	MaxEIRP
1	MaxEIRP 2 dB
2	MaxEIRP 4 dB
3	MaxEIRP 6 dB
4	MaxEIRP 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8 ~ 15	RFU

## EU433

By default, MaxEIRP is considered to be +12.15 dBm.

<b>TXPower</b>	<b>Configuration (EIRP)</b>
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6 ~ 15	RFU

[Back](#)

## Appendix III Maximum Transmission Load by Region

 **NOTE:**

M in the following list is the length with MAC header, N is the maximum usable payload size for the user data without MAC header.

### EU868

<b>Data Rate</b>	<b>M</b>	<b>N</b>
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6	250	242
7	250	242
8 ~ 15	Not Defined	Not Defined

### US915

Data Rate	M	N
0	19	11
1	61	53
2	133	125
3	250	242
4	250	242
5 ~ 7	Not Defined	Not Defined
8	61	53
9	137	129
10	250	242
11	250	242
12	250	242
13	250	242
14 ~ 15	Not Defined	Not Defined

AU915

Data Rate	M	N
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6	250	242
7	Not Defined	Not Defined
8	61	53
9	137	129
10	250	242
11	250	242
12	250	242
13	250	242
14 ~ 15	Not Defined	Not Defined

**KR920**

Data Rate	M	N
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6 ~ 15	Not Defined	Not Defined

**AS923**

Data Rate	Uplink MAC Payload Size (M)		Downlink MAC Payload Size (M)	
	UplinkDwellTime = 0	UplinkDwellTime = 1	DownlinkDwellTime = 0	DownlinkDwellTime = 1
0	59	N/A	59	N/A
1	59	N/A	59	N/A
2	59	19	59	19
3	123	61	123	61
4	250	133	250	133
5	250	250	250	250
6	250	250	250	250
7	250	250	250	250
8	RFU		RFU	

**IN865**

<b>Data Rate</b>	<b>M</b>	<b>N</b>
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6	250	242
7	250	242
8 ~ 15	Not Defined	Not Defined

**RU864**

<b>Data Rate</b>	<b>M</b>	<b>N</b>
0	59	51
1	59	51
2	59	51
3	123	115
4	230	222
5	230	222
6	230	222
7	230	222
8 ~ 15	Not Defined	Not Defined

**CN470**

<b>Data Rate</b>	<b>M</b>	<b>N</b>
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6 ~ 15	Not Defined	Not Defined

**EU433**

<b>Data Rate</b>	<b>M</b>	<b>N</b>
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6	250	242
7	250	242
8 ~ 15	Not Defined	Not Defined

[Back](#)